



AVAILABLE CRACKLE COLORS:



EC8004 Copper Brown RAL8004 TNR: 416471



EC7000 Squirrel Grey RAL7000 TNR: 418464



EC5010 Gentian Blue RAL5010 TNR: 416440



EC9010 Pure White RAL9010 TNR: 418488



EC6000 Patina Green RAL6000 TNR: 418457



EC9017 Traffic Black RAL9017 TNR: 418495

CRACKLE CRA

For the special crackle- or used-look. Prior coating of the object is necessary with colors of Montana GOLD (recommended) or Montana WHITE (the thicker the base coat the stronger the effect). Give at least 45min but not more than 24hours drying time to the base coat before applying CRACKLE effect. While spraying change directions (crosscoat) for best coating results. After extensively applying CRACKLE to your primed area, the distressing process will begin to occur. CRACKLE can be top-coated when fully dry and cured (after 24h) with Montana GOLD, BLACK, WHITE, Montana ACRYLIC markers as well as customary acrylic paints. Pre Priming with Montana Styrofoam primer is required for application on polystyrene. Available in 6 RAL colors. More information on:

VIDEO: WWW.MONTANA-CANS.COM/HOWTO

